

# Basic Alarm Functions

## To Arm When Going Out:

When the “Ready” light is green, press and hold the “Away” button for 2-3 seconds (release button after you hear the beep) and then exit your home.

(If the “Ready” light is not green, close all doors/windows and stop any movement in front of motion detectors. The ready light should turn green. If it doesn’t, call the installer or see below for bypass instructions.)

## To Arm When Staying Home:

When the “Ready” light is green, press and hold the “Stay” button for 2-3 seconds (release button after you hear the beep.)

(If the “Ready” light is not green, close all doors/windows and stop any movement in front of motion detectors. The “ready” light should turn green. If it doesn’t, call the installer or see below for bypass instructions.)

## To Disarm When Returning Home:

Enter your 4-digit code.

(If a mistake is made while entering your code, press the # key and start again.)

## To Disarm When Staying Home:

Enter your 4-digit code.

(The “stay” mode will enable you to move about the house without tripping the motion detectors.)

## If Fire Alarm Sounds:

Check for Fire

Enter your 4-digit code to silence alarm

Red light on tripped detector will remain lit

### After Smoke has Cleared:

Press and hold Reset button on keypad for 3 Seconds to turn light off

## To Bypass a Zone:

(The “bypass” mode will enable you to arm the system when zones are open, or when a zone will not close.)

To bypass press the following:

\* (star key)

1 (the number 1 key)

Zone number (In two digits, i.e. zone 2 would be entered as 02)

# (pound key)

Then arm as usual, using either the “Stay” or “Away” button.

Zone bypassing is automatically cleared each time the system is disarmed.